

Mini Plug-In Air Purifier User Guide

Item: 779530



Ginnys.com • 800-544-1590

f Facebook.com/GinnysBrand

Pinterest.com/GinnysBrand

Thank you for purchasing a Ginny's Brand Mini Plug-In Air Purifier. This easy-to-operate air purifier is silent and has no batteries or filters to replace! Use it in your bathroom, closet or by your pet's bed or litter box to sanitize the air and reduce odors (it also reduces airborne allergens). Breathe freely!

TABLE OF CONTENTS

Important Safeguards	3
Electrical Safety and Specifications	4
Get to Know Your Appliance	5
How to Operate	6
Cleaning & Care	7
Warranty	8

IMPORTANT SAFEGUARDS

READ CAREFULLY BEFORE USING AND SAVE THESE INSTRUCTIONS!


- FOR HOUSEHOLD USE ONLY. DO NOT USE THIS ITEM FOR OTHER THAN ITS INTENDED USE.
- Remove all packaging materials and labels before first use.
- DO NOT use an extension cord with this item.
- CLOSE SUPERVISION IS NECESSARY WHEN USING THIS ITEM NEAR CHILDREN.
- This air purifier is recommended for use in small rooms only.
- DO NOT operate the unit if flammable or combustible vapors are present.
- A fire may occur if this air purifier is used near flammable materials, including curtains, towels, walls, etc. DO NOT place the air purifier on or near a heated surface or in a heated oven.
- The filter plates should be inspected frequently. Excessive accumulation on the plates may result in an electrical flashover or a risk of fire.
- DO NOT use near water.
- DO NOT touch the unit or its plug when your hands are wet.
- DO NOT use an accessory or attachment not recommended by Ginny's, as this may cause personal injury or damage the air purifier.
- DO NOT use outdoors.
- Always remove the unit from the electrical outlet by holding firmly and pulling gently.
- Keep fingers, hair, loose clothing and jewelry away from openings.
- THERE ARE NO SERVICEABLE PARTS INSIDE THIS ITEM. DO NOT open the housing.
- DO NOT USE THIS ITEM WITH A DAMAGED PLUG, OR AFTER IT HAS MALFUNCTIONED OR HAS BEEN DAMAGED IN ANY MANNER. DO NOT OPERATE IF THE LAMP IS BROKEN.
- Electronic devices contain valuable materials that can be recycled.
 Dispose of old items using appropriate collection systems in accordance with federal and local regulations.

ELECTRICAL SAFETY

This appliance is equipped with a plug with 2 straight prongs. If the plug does not fit into your electrical outlet, contact a qualified electrician. DO NOT attempt to modify the plug in any way. Ginny's cannot accept any liability for damage or injury resulting from failure to observe these safety procedures.

SPECIFICATIONS		
POWER RATING	120V, 60Hz, 8W	
DIMENSIONS	4" W x 8" H x 3½" D	
MODEL	TPP50GB	

GET TO KNOW YOUR APPLIANCE



- 1. Housing
- 2. Front Window
- 3. UV Lamp (inside)
- 4. Removable Filter Plates (2)
- 5. 2-Prong Plug (not shown, on back)

HOW TO OPERATE

WARNINGS:

- UV Light is harmful to bare skin and eyes and can cause temporary or permanent loss of vision. Never look directly at the UV lamp while it is illuminated; only view illumination through the window at the front of the unit.
- UV lamps contain mercury. If a lamp breaks, unplug the unit.
 Sweep the debris into a plastic bag and contact local waste management for disposal instructions.
- 1. To turn on the air purifier, simply plug it into an electrical outlet.
- 2. The air purifier will immediately light up and the interior fan will gently cycle air through the filter plates.

CLEANING & CARE

- 1. Always unplug the air purifier from the electrical outlet before cleaning.
- Hold the unit with one hand and gently pull down to remove the filter plates (one on the right bottom and one on the left bottom) from the housing.
- 3. Wipe the plates clean using a **dry** soft cloth or paper towel. DO NOT use abrasive pads or cleaning solutions.
- 4. If the filter plates become wet or damp, set them aside for 24 hours to dry completely before reinstalling in the housing.
- 5. Reinstall the filter plates in reverse order.
- 6. As needed, wipe the exterior of the housing with a dust cloth.
- 7. DO NOT immerse the air purifier, filter plates or plug into water.
- 8. When filters are reinstalled, plug the air purifier back into the electrical outlet to operate.

WARRANTY

Ginny's warrants this product free from defects in material and workmanship for one year from provable date of purchase.

Within this warranty period, Ginny's will repair or replace, at its option, defective parts at no charge provided the product is returned freight prepaid with proof of purchase to Ginny's.

Allow 2–4 weeks for return shipping.

This warranty does not cover improper installation, misuse, abuse or neglect on part of the owner. Warranty is also invalid in any case that the product is taken apart or serviced by an unauthorized service station.

This warranty gives you specific legal rights and they may vary from state to state.

THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES AND CONDITIONS, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THOSE OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.



Ginny's, Inc. 1112 7th Avenue Monroe, WI 53566

Customer Service: 800-544-1590 8:00 a.m. to Midnight CST, Monday through Friday